

straightcurve®

560mm Zero-Flex Installation Guide

CONTENTS



2 x Length 1800 mm



4 x Bracing rod



8 x Fixing Spike



2 x Join bracket



1 x Join set
(8 x sliders + wedges)


RECOMMENDED TOOLS

- Ground leveling tools
- Hammer
- Rubber mallet
- Angle grinder (only required if modifying lengths or fashioning ends)


PREPARATIONS

The Zero-Flex Raised Garden Bed requires NO digging in as its feet are secured to the ground surface. The base should be smoothed/leveled for the edge to sit flush on the ground during installation. Any obstructions should be removed or re-routed. It can be installed on all level ground types including concrete surfaces (where packers are used to sit edge off ground to allow drainage). For smooth connecting, use the cardboard under joins when connecting with the panel face down on flat ground. Grass and debris likes to get caught in the tight seam!


Step-by-Step Installation




STEP 1 - Sketch out the shape of your Garden Bed including dimensions of all sides. Define the lengths and corners you need.




STEP 2 - Mark edge lines on ground and layout edge pieces nearby.




STEP 3 - Place first two edges front face down on the ground with a gap and the join slots aligned.




STEP 4 - Join using the joining set, first break the pieces apart by hand. Slide the joining plate under the folded top with the bottom of the plate in the slot on the flange. Use a hammer to hammer it into position.




STEP 5 - Slide the other edge over the joining plate. Use a hammer to hammer it into position.




STEP 6 - Insert the L-shaped slider (A) through adjacent bottom slot.




STEP 7 - Hammer the wedge (B) in firmly and repeat step 6 for the other slot.




STEP 8 - Set these two edges upright and position where desired, use fixing spikes as temporary placeholders.




STEP 9 - Introduce further lengths against the now standing edge, connecting them as you go.




STEP 10 - Check the line, then hammer all fixing spikes through foot tab holes.



STEP 11 - Now attach the turnbuckle of the Universal Bracing Set to the top bracing lip. Use the maximum length of the chain where possible, if shorter a minimum 45 degree angle is required. Then hammer the T shaped stake to secure the panel.
Bracing set sold separately



STEP 12 - Use the turnbuckle for fine adjustments



STEP 13 - Backfill to finish.

DO...

- ✓ Check the line with a string line as you add more panels
- ✓ Start from the corner if using a pre made one
- ✓ Score an intermittent line rather than one deep score line if making corners
- ✓ Follow the instructions and do it with a friend to make it more enjoyable
- ✓ If installing on a hard surface line the bed to prevent grit spill

DON'T...

- ✗ Use for curved line designs, instead use Flex Raised Garden Bed
- ✗ Set directly onto a hard surface without raising slightly with packers
- ✗ Accelerate rust with acids or salts (but soapy water is ok!)
- ✗ Forget the safety gloves when working with steel!



Scan to watch the installation video

Do you want more detailed information?



Scan me for product catalogue

